



POLLINGUARDTM
breathe with ease

INSTALLATION GUIDE FOR POLLINGUARDTM NANOFIBERTM FLYSCREEN

1. REMOVE SPLINE & EXISTING MESH (if re-meshing).
2. LAY FRAME ON A FLAT SURFACE AND DRAPE POLLINGUARD MESH OVER IT.
3. CUT THE POLLINGUARD MESH WITH 20mm OVERLAP ON ALL FOUR SIDES.
4. APPLY NEW SPLINE (DO NOT USE THE OLD). NEW SPLINES CAN BE PURCHASED FROM ANY HARDWARE STORE, FOAM SPLINE RECOMMENDED.
5. NEW SPLINE THICKNESS SHOULD BE THE SIZE OF YOUR FLYSCREEN'S SLOT.
6. START SPLINING APPROXIMATELY 90mm FROM ONE CORNER TO ALLOW STRETCHING AS YOU GO AROUND THE FRAME.
7. USE SPLINE ROLLER TO PUSH THE SPLINE INTO THE SLOT.
8. TRIM THE EXCESS SPLINE AND MESH WITH A SHARP STANLEY KNIFE OR BLADE.

CLEANING GUIDE FOR POLLINGUARDTM NANOFIBERTM FLYSCREEN

USE MILD pH-NEUTRAL DETERGENT AND WIPE THE SCREENS GENTLY WITH A MICROFIBER GLOVE OR CLOTH FOLLOWED BY LOW PRESSURE RINSE.

POLLINGUARD FLYSCREENS SHOULD BE CLEANED TWICE YEARLY, ONCE BEFORE THE POLLEN SEASON AND ONCE, AFTER THE POLLEN SEASON.

REFER TO OUR POLLEN CALENDARS FOR YOUR CITY.

<https://www.pollinguard.com.au/pollen-calendars>